R19 V2016

KA1 : Relays card
KA8 : Fuel pump Relay
KA8 : relays card (anti-start/Pickup)
KA9 : Power start-up relay
KA10 : Cooling fan relay (option)
KA11 : relays 70a alimentation the roof of the cabin DELUX
KA12 : Relais air conditioning compressor cabine DELUX

Operator Box
Control Handle
Light front right
Light front left
Cabin option Apple or Nuts Rotary light
Cabin top conector
Front working lights
Work light behind the seat
Horn
Seat switch
Engine screen
Engine accelerator
Pickup enable
Hopper leveller
pickup/rotor switch
hopper/pickup enable
Floating pickup adjustement
Fan
Blower
Option sweeper 1000
Option sweeper 600
Option floating pickup
Mechanical speed 2
Searing Column
DELUX CABIN
terminal block
motor diagnosis catch
RELAYS CARD KA8
RELAYS CARD KA1
SKIM INTERFACE
In the white box
Checkvalves
Fuel pump
Cooling Fan
SPEED SENSOR AVANCEMENT
Battery box
Battery
cutout battery
motor
water presence in gas oil
air conditioning compressor
Advancement C02
Advancement C01
offsetting without
Calculateur moteur
Connector X23.1
Connector X23.2
Rear right lights
Left rear Light
ultrasound sensor 32
ultrasound sensor 70 (option)
Blower
Pick up
Crabes
C1 GREY
C2 BLACK
AUTOMOTIVE SAUER M0824-021

1	sidelights					
2	Breaking lights					
3	Right Indicators					
4	Ground					
5	Left Indicators					
6	Working lights					
7						

1	Black Sidelights
2	Red Breaking light
3	Yellow Indicator
4	White

1	Black
2	Purple
3	Grey/pink
4	Red/blue
5	White/green
6	Ground/green
7	White/yellow
8	Yellow/ground

1	Black
2	Purple
3	Ground/pink
4	Red/blue

1	Green
2	Grey/pink
3	Red/blue
4	White/green
5	Brown/green
6	White/yellow
7	Yellow/brown

53	CAN - CUSTOMER
54	CAN L DIAG
55	CAN H DIAG
57	CAN + CUSTOMER
1	
2	Speed
3	pickup ON/OFF
4	
5	hopper emptying
6	Hopper rear
7	pickup raise
8	pickup Lower
9	hopper raise
10	hopper lower
11	Fuel gauge
12	+ Accelerator potentiometer
13	gasoil water presence
14	gasoil water presence
15	- Accelerator potentiometer
16	Side-lights
17	Left indicator
18	Right indicator
19	accelerator deposit
20	Blower
21	Work light
22	
23	hopper equalizer/test carpet
24	
25	+ after contact
25	+ after contact
25	+ after contact
26	pickup ON
27	+ before contact
27	+ before contact
28	Speed Information
29	Brake
30	harvesting relay ON
31	ADVANCEMENT INFORMATION
32	Hopper filling 1
33	Offsetting -
34	Offsetting +
35	Forward gear C02
36	Reverse gear C01
37	Alimentation 5V
38	Ground 5V
39	air conditioning compressor
40	Reversible blades (option)
41	after sensor information
42	rear sensor information
43	
44	Offsetting start-up
45	Mecanical speed 2 information
46	Mecanical speed 2 control
47	test carpet inversion
48	ventilation potentioneter
49	Rotor Inversion
50	level indicator hydraulic oil mini hydraulic oil mini
71	Floating pickup alimentation
51	Floating pickup value
051	Floating value
70	hopper filling 2 (option)
290	anti-starting safety

Ce plan est la propriété exclusive de AMB ROUSSET, il ne peut être reproduit, utilisé ou communiqué sans autorisation

Tolérance générale du plan ±0.5mm

Ets ROUSSET
38470 BEAULIEU
tel:04.76.36.73.73
fax:04.76.36.70.82

SCHEMAS ELECTRIQUE
Complet R19

N° : R19-AUD-L40-009961_0M

Échelle

Matière : Traitement : Ep :

Ind.	Modification	Date	Nom	1ère saison
0M	Modèle 2016 1ere et 2e serie	16/02/2016	JOURDAN	
0L	Modèle 2015 4e serie	02/09/2015	CAILLAT	
0K	Modèle 2015 3e serie	02/09/2015	CAILLAT	

Utilisé dans	Qté	Expire
R19 AUD	0	